






EMERALD







7 Let go of the canopy in a horizontal position.

If the canopy moves up by itself, adjust the ball-end bolts towards 'A'

If the canopy moves down by itself, adjust the ball-end bolts towards 'B'

Removing the acrylic plate

